



# 2004-2008 Audi A4 (B7) Ignition Coil Replacement

Video guide on how to repair, install, fix, change or replace a bad or broken ignition coil or coil pack on a 2005-2008 Audi A4.

Written By: eCuration



## INTRODUCTION

One of the most common symptoms associated with a faulty ignition coil is engine performance issues.

If you are experiencing misfires, a rough idle, loss of power, and or a reduction in gas mileage then follow this video guide to replace the ignition coils yourself.



### TOOLS:

- [T20 Torx Screwdriver](#) (1)
- [Flathead Screwdriver](#) (1)



### PARTS:

- [Ignition Coil](#) (1)
-

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 03:43:52 PM.